



Technical Bulletin

Trio Motion Technology Ltd.
Shannon Way,
Tewkesbury
Glos. GL20 8ND U.K.

Tel: 01684 292333
Fax: 01684 297929
Email: apps@triomotion.com
Web: www.triomotion.com

Doc No.: TN20-23
Version: 1.0
Date: 17 September 1998
Subject: Keypad Control Codes (Mini Membrane)

Details: The mini-membrane keypad uses a slightly different driver circuit which features a number of additional control codes for enhanced features.

The codes which are implemented to enable and disable the cursor display have been changed thus:

Code	Membrane	Mini Membrane
20	Cursor OFF	Cursor _
21	Flashing ■	Flashing ■
22	Cursor OFF	Cursor OFF
23	Cursor OFF	Flashing _

Therefore for compatibility with both keypads, it is recommended that following codes are used:

21 cursor ON
22 cursor OFF