

Symbols

- 8-131
8-126
\$ 8-126
* 8-132
+ 8-131
/ 8-132
: 8-124
< 8-135
<= 8-135
<> 8-133
= 8-133
> 8-134
>= 8-134
' 8-125

Numerics

100-Way MDR Connector 2-4
2.5m 100 Way Cable 1-5
4 Axis DAC Module 1-5
5 Volt Supply 2-8
8 Axis DAC Module 1-5

A

ABS 8-136
ACC 8-10
ACCEL 8-150
ACOS 8-136
ADD_DAC 8-10
ADDAX 8-11
ADDAX_AXIS 8-150
Additional Servo Axis 1-5
Additional Stepper Axis 1-5
ADDRESS 8-78
AIN 8-44
AIN0-7 8-45
AINBIO-7 8-45
AMP_STATUS 8-150
AND 8-136

APPENDPROG 8-78
Applications 1-9
ASIN 8-137
ATAN 8-138
ATAN2 8-138
ATYPE 8-151
AUTORUN 8-78
AXIS 8-13
Axis Configuration 4-3
AXISSTATUS 8-152
AXISVALUES 8-79

B

Backplate 2-10
BASE 8-14
BASICERROR 8-65
bi-directional 5-3
Board 11-7
BOOST 8-153
Breakout Board 1-5, 2-5
Breakpoints 10-61
Bus Wiring 5-5

C

CAD2Motion 10-74
CAM 8-15
CAMBOX 8-18
CAN 8-79
CAN 16 I/O Module 1-5
CAN Analog Input Module 1-5
CAN connections 2-8
CAN_ADDRESS 8-153
CAN_ENABLE 8-153
CANCEL 8-25
CANIO_ADDRESS 8-81
CANIO_ENABLE 8-82
CANIO_STATUS 8-82
CANopen 5-3
Changing Axis ATYPE 4-4
CHECKSUM 8-82

CHR 8-46
CLEAR 8-83
CLEAR_BIT 8-139
CLEAR_PARAMS 8-83
CLOSE_WIN 8-153
CLUTCH_RATE 8-154
COMMSERROR 8-84
COMMSTYPE 8-85
COMPILE 8-85
CONNECT 8-26
CONSTANT 8-139
CONTROL 8-85
COPY 8-86
COS 8-140
CREEP 8-154
CURSOR 8-45

D

D_GAIN 6-11, 8-158
DAC 8-155
DAC_OUT 8-156
DAC_SCALE 8-156
DATE 8-86
DATES 8-86
DATUM 8-27
DATUM_IN 8-157
DAY 8-87
DAYS 8-87
DEC 8-28
DECEL 8-157
DEFKEY 8-46
DEFPOS 8-29
DEL 8-87, 8-88
DEMAND_EDGES 8-157
Derivative gain 6-11
Desktop 10-12
DEVICENET 8-88
DeviceNet 5-3
Diagnostic Checklists 6-14
DIP Switch Settings 5-6, 5-12
DIR 8-88
DISPLAY 8-89
DLINK 8-89
DocMaker 10-75

DPOS 8-158
DUAL IO Mapping 5-7

E

EDIT 8-95
EDPROG 8-94
ELSE 8-65, 8-70
ELSEIF 8-65
EMC 3-4
EMC Directive 3-4
Enable 2-6, 2-11
ENCODER 8-158
Encoder/Stepper Connectors 2-5
ENDIF 8-67, 8-70
ENDMOVE 8-159
EPROM 8-95
Error Codes 5-8
ERROR_AXIS 8-96
ERROR_LINE 8-127
ERRORMASK 8-159
ETHERNET 8-96
EX 8-97
Example Programs 9-3
EXECUTE 8-97, 8-98
EXP 8-140

F

FALSE 8-148
FAST_JOG 8-160
FASTDEC 8-160
FE 8-160
FE_LIMIT 8-160
FEATURE_ENABLE 8-98
FEGRAD 8-161
FEMIN 8-161
FERANGE 8-161
FHOLD_IN 8-161
FHSPEED 8-162
FLAG 8-47
FLAGS() 8-48
Flash Eprom 10-65
FLASHVR 8-100
FLASHVR() 8-100
FOR 8-67

FORWARD 8-30
FRAC 8-140
FRAME 8-101
FREE 8-101
FS_LIMIT 8-162
FWD_IN 8-163
FWD_JOG 8-163

G

Gains 6-9
GET 8-48
GET# 8-49
GetConnectionType 11-6
GLOBAL 8-141
GOSUB 8-68
GOTO 8-69

H

HALT 8-103
HEX 8-50
HostAddress 11-7

I

I_GAIN 6-11, 8-164
IDLE 8-70, 8-75
IEEE_IN 8-139, 8-141
IEEE_OUT 8-142
IF 8-70
IN 8-50
INDEVICE 8-127
INITIALISE 8-103
INPUT 8-51
Inputs 2-7
INPUTS0/INPUTS1 8-52
Install 6-4
Installation 3-1, 11-3
INT 8-142
Interpolation 2-9
INVERT_IN 5-7, 8-52
INVERT_STEP 8-163
IsOpen 11-5

J

JOGSPEED 8-164

K

KEY 8-52

L

LAST_AXIS 8-103
LED Indicators 5-7
LENZE 5-7
LINKAX 8-164
LINPUT 8-53
LIST 8-104
LN 8-143
LOADED 8-76
LOADSYSTEM 8-104
LOCK 8-105
LOOKUP 8-128

M

MARK 8-165
MARKB 8-165
MATCH 8-30
MC Simulation 10-71
Memory 2-9
MERGE 8-165
MHELICAL 8-31
MICROSTEP 8-166
MOD 8-143
MOTION 8-106
Motion Coordinator 1-3
Motion Perfect 10-3
 Communications 10-66
 Flashstick Support 10-20
 Analogue Input Viewer 10-46
 Axis Parameters 10-24
 Connecting to a Controller 10-7
 Control Panel 10-49
 Controller Configuration 10-15
 Debugger 10-60
 Desktop 10-12
 Digital IO Status 10-44

- Editor 10-55
- External Tools 10-47
- Feature Enable 10-16
- Jog Axes 10-40
- Keypad
 - Emulation 10-37
- Loading System Software 10-18
- Lock/Unlock Controller 10-21
- Main Menu 10-13
- New Features 10-6
- Oscilloscope 10-27
- Projects 10-8
- Setting Powerup Mode 10-64
- System Requirements 10-4
- Table/VR Editor 10-39
- Terminal 10-23
- Tools 10-22

MOTION_ERROR 8-106

MOVE 8-32

MOVEABS 8-33

MOVECIRC 8-35

MOVELINK 8-36

MOVEMODIFY 8-40

MPE 8-106

MPOS 8-167

MSPEED 8-167

MTYPE 8-167

Multifunction Adapters 6-4

N

NAIO 8-107

NETSTAT 8-107

NEW 8-108

NEXT 8-67, 8-71

NIO 8-108

NOT 8-143

NTYPE 8-168

O

OCX 11-1

OFF 8-148

OFFPOS 8-168

ON 8-148

ON .. GOSUB 8-71

ON .. GOTO 8-72

OP 8-54

OPEN_WIN 8-169

OR 8-144

OUTDEVICE 8-128

OUTLIMIT 8-169

Output Velocity Gain 6-12

Outputs 2-6

OV_GAIN 6-12, 8-170

P

P_GAIN 6-11, 8-171

P180 1-5

P181 1-5

P182 1-5

P183 1-5

P184 1-5

P185 1-5

P187 1-5

P315 1-5

P325 1-5

PCI 208 1-3

PCI 208 Block Diagram 2-4

PCI Port 2-9

PCI slot 1-4

PEEK 8-109

PI 8-149

PMOVE 8-128

POKE 8-109

Position Resolution 2-9

Power Input 2-9

POWER_UP 8-109

PP_STEP 8-171

PRINT 8-55

PRINT# 8-56

PROC 8-129

PROC_LINE 8-129

PROC_STATUS 8-129

PROCESS 8-110

PROCNUMBER 8-129

Products 1-5

- I/O Expansion options 1-6

- Master Controllers 1-5

PROFIBUS 8-110

Programming 2-9, 7-1
Project Autoloader 10-76
Proportional Gain 6-11
PSWITCH 8-57

R

RAPIDSTOP 8-43
READ_BIT 8-145
READPACKET 8-59
RECORD 8-60
REG_MATCH 8-172
REG_POS 8-172
REG_POSB 8-173
REGIST 8-41
REMAIN 8-173
REMOTE 8-111
REMOTE_ERROR 8-174
RENAME 8-111
REP_OPTION 8-174
REPDIST 8-174
REPEAT 8-72
RESET 8-130
Resolution 2-9
RETURN 8-73
REV 8-175
REV_IN 8-175
REV_JOG 8-175
REVERSE 8-43
RS_LIMIT 8-175
RUN 8-111
RUN_ERROR 8-130
RUNTYPE 8-112

S

SCOPE 8-112
SCOPE_POS 8-113
SELECT 8-114
SEND 8-60
SERVO 8-176
Servo Cycle 2-9
Servo Gains 6-9
Servo Loop 6-13
Servo Loop Diagram 6-13
SERVO_PERIOD 8-114

SET_BIT 8-145
SETCOM 8-61
SGN 8-145
Simplest Possible System 1-6
SIN 8-146
Size 2-9
SLM 8-89
SLOT 8-114
SP() 8-176
SPEED 8-177
SQR 8-146
SRAMP 8-177
SSI_BITS 8-177
STEP 8-67, 8-73
STEPLINE 8-115
STICK_READ 8-115
STICK_WRITE 8-116
STOP 8-73, 8-74
STORE 8-116
System Examples 1-6
System Setup 6-3

T

TABLE 8-117
TABLEVALUES 8-118
TAN 8-147
Temperature 2-9
Testing Standards 3-5
THEN 8-70, 8-73, 8-74
TICKS 8-130
TIME 8-119
TIMES 8-119
TO 8-67, 8-74
TRANS_DPOS 8-178
TRANSITIONS 8-178
TRIGGER 8-119
Trio BASIC 1-3
TRIO Protocol 5-6
TROFF 8-119
TRON 8-120
TRUE 8-149
TSIZE 8-120
Typical Applications 1-9
Typical applications 1-9

U

UNITS 8-178
UNLOCK 8-120
UNTIL 8-72, 8-74, 8-76
USB 8-121
USB_STALL 8-122

V

Velocity Feed Forward Gain 6-12
VERIFY 8-179
VERSION 8-122
VFF_GAIN 6-12, 8-180
VIEW 8-122
Voltage I/O 2-6
VP_SPEED 8-180
VR 8-123, 8-180

W

WA 8-75
WAIT 8-75
WAIT IDLE 8-75
WAIT LOADED 8-76
WAIT UNTIL 8-76
Watchdog 2-11
WDOG 8-124
Weight 2-9
WEND 8-77
WHILE 8-77
Windows 2000 1-4
Windows XP 1-4

X

X11 2-6
X17 2-7
X9 2-6
XOR 8-147